

LD 83: Terminal Number Sort and Print

Overlay program 83 allows the printing of a list of TNs and of TN blocks in Designation (DES) order.

In Release 18, "MARF" is output after the DN when printing the TN block (NOT when using the LST command) if the TN is the Multiple Appearance Redirection Prime.

Prompts and responses

Prompt	Response	Comment
REQ	aaa	Request (aaa = END, LST, TNB)
CUST	xx xx	Customer number or range of customer numbers
DATE	a...a	Print data from activity date specified or last activity date (You may enter : dd mmm yyyy or ACT)
PAGE	(NO) YES	Data printed on a per-page basis
- ADJUST PAPER THEN <cr>	<cr>	Starts printing
NACT	(NO) YES	Next Activity

Alphabetical list of prompts

Prompt	Response	Comment	Pack/Rel
ADJUST PAPER THEN	<cr>	Starts printing	odas-1
CUST	xx xx <cr>	Customer number or range of customer numbers Print data date for all customers	odas-1
DATE	dd mmm yyyy	Print data from activity date specified. Where: • dd = day (0-31) • mmm = month (JAN-DEC) • yyyy = year	odas-1
	ACT <cr>	Print data from last activity date Disregard date restrictions	
NACT	(NO) YES END	Next Activity Return to REQ prompt Print current system data and exit overlay Exit Overlay program	odas-1
PAGE	(NO) YES	Data printed on a per-page basis	odas-1
REQ	END LST TNB	Request Exit Overlay program Print List of TNs in designator order Print list of TN blocks in designator order	odas-1